

Use in DC current mode.

Connect the detector to current input.

From this glass plate

Polarized light source. You can rotate the laser to change the polarization